



Frameless Whiteboard

Instruction leaflet


FWB3045	30 x 45 cm	FWB100100	100 x 100 cm
FWB4560	45 x 60 cm	FWB100150	100 x 150 cm
FWB6090	60 x 90 cm	FWB100200	100 x 200 cm
FWB80110	80 x 110 cm	FWB120180	120 x 180 cm
FWB90120	90 x 120 cm		




±10 min



x 1






Vertical




Horizontal


Parts and tools




STEP 1



STEP 2



STEP 3



Dry wipe surface. Never clean it with alcohol or abrasive products as the surface may be damaged. Please use a wet cloth to erase the surface.
This product do not need any especial attention in the use or basic knowledge of its parts for it use is free of any security advertise.